

14x4in1 led wall washer manual(RGBW)

3CH	Function	DMX Value	Description
1	Red	0-255	0-100%
2	Green	0-255	0-100%
3	Blue	0-255	0-100%

4CH	Function	DMX Value	Description
1	Red	0-255	0-100%
2	Green	0-255	0-100%
3	Blue	0-255	0-100%
4	White	0-255	0-100%

6CH	Function	DMX Value	Description
1	Dimmer	0-255	0-100%
2	Strobe	0-19	No Effect
		20-255	Strobe slow to fast
3	Red	0-255	0-100%
4	Green	0-255	0-100%
5	Blue	0-255	0-100%
6	White	0-255	0-100%

56CH	Function	DMX Value	Description
1	Red1	0-255	0-100%
2	Green1	0-255	0-100%
3	Blue1	0-255	0-100%
4	White1	0-255	0-100%
5	Red2	0-255	0-100%
6	Green2	0-255	0-100%
7	Blue2	0-255	0-100%
8	White2	0-255	0-100%
...
49	Red13	0-255	0-100%
50	Green13	0-255	0-100%
51	Blue13	0-255	0-100%
52	White13	0-255	0-100%
53	Red14	0-255	0-100%
54	Green14	0-255	0-100%

55	Blue14	0-255	0-100%
56	White14	0-255	0-100%

58CH	Function	DMX Value	Description
1	Dimmer	0-255	0-100%
2	Strobe	0-19	No Effect
		20-255	Strobe slow to fast
3	Red1	0-255	0-100%
4	Green1	0-255	0-100%
5	Blue1	0-255	0-100%
6	White1	0-255	0-100%
7	Red2	0-255	0-100%
8	Green2	0-255	0-100%
9	Blue2	0-255	0-100%
10	White2	0-255	0-100%
...
51	Red13	0-255	0-100%
52	Green13	0-255	0-100%
53	Blue13	0-255	0-100%
54	White13	0-255	0-100%
55	Red14	0-255	0-100%
56	Green14	0-255	0-100%
57	Blue14	0-255	0-100%
58	White14	0-255	0-100%

12CH	Function	DMX Value	Description
1	Dimmer	0-255	0-100%
2	Strobe	0-19	No Effect
		20-255	Strobe slow to fast
3	Red	0-255	0-100%
4	Green	0-255	0-100%
5	Blue	0-255	0-100%
6	White	0-255	0-100%
		0-10	No Function
		11-30	R 100%,G 50-100-50%,B 0
		31-50	R 100%-0,G 100%, B,0

7	Color Macro	51-70	R 0,G 100%,B 0-100%
		71-90	R 0,G 100%-0,B 100%
		91-110	R 0-100%, G 0, B 100%
		111-130	R 100%,G 0, B 100%-0
		131-150	R 100% ,G 0-100% ,B 0-100%
		151-170	R 100%-0 , G 100%-0 , B 100%
		171-200	R 100%,G 100%, B 100%
		201-205	Color 1
		206-210	Color 2
		211-215	Color 3
		216-220	Color 4
		221-225	Color 5
		226-230	Color 6
		231-235	Color 7
		236-240	Color 8
		241-245	Color 9
		246-250	Color 10
251-255	Color 11		
8	Foreground Dimmer	0-255	0-100%
9	Background	0-10	No Function
		11-255	Background Color
10	Background Dimmer	0-255	0-100%
		0-10	No Function
		11-15	Show1
		16-20	Show2
		21-25	Show3
		26-30	Show4
		31-35	Show5
		36-40	Show6
		41-45	Show7
		46-50	Show8
		51-55	Show9
		56-60	Show10
		61-65	Show11
		66-70	Show12
		71-75	Show13
		76-80	Show14
81-85	Show15		

11	Show	86-90	Show16
		91-95	Show17
		96-100	Show18
		101-105	Show19
		106-110	Show20
		111-115	Show21
		116-120	Show22
		121-125	Show23
		126-130	Show24
		131-135	Show25
		136-140	Show26
		141-145	Show27
		146-150	Show28
		151-155	Show29
		156-160	Show30
		161-165	Show31
		166-170	Show32
		171-175	Show33
		176-180	Show34
		181-185	Show35
		186-190	Show36
		191-195	Show37
		196-200	Show38
		201-205	Show39
206-210	Show40		
211-215	Show41		
216-220	Show42		
221-225	Show43		
226-230	Show44		
231-235	Show45		
236-245	Sound1		
246-255	Sound2		
12	Show Speed	0-255	Show Speed Slow to Fast

64CH	Function	DMX Value	Description
1	Dimmer	0-255	0-100%
2	Strobe	0-19	No Effect
		20-255	Strobe slow to fast

3	Red1	0-255	0-100%
4	Green1	0-255	0-100%
5	Blue1	0-255	0-100%
6	White1	0-255	0-100%
7	Red2	0-255	0-100%
8	Green2	0-255	0-100%
9	Blue2	0-255	0-100%
10	White2	0-255	0-100%
...
51	Red13	0-255	0-100%
52	Green13	0-255	0-100%
53	Blue13	0-255	0-100%
54	White13	0-255	0-100%
55	Red14	0-255	0-100%
56	Green14	0-255	0-100%
57	Blue14	0-255	0-100%
58	White14	0-255	0-100%
59	Color Macro	0-10	No Function
		11-30	R 100%,G 50-100-50%,B 0
		31-50	R 100%-0,G 100%, B,0
		51-70	R 0,G 100%,B 0-100%
		71-90	R 0,G 100%-0,B 100%
		91-110	R 0-100%, G 0, B 100%
		111-130	R 100%,G 0, B 100%-0
		131-150	R 100% ,G 0-100% ,B 0-100%
		151-170	R 100%-0 , G 100%-0 , B 100%
		171-200	R 100%,G 100%, B 100%
		201-205	Color 1
		206-210	Color 2
		211-215	Color 3
		216-220	Color 4
		221-225	Color 5
		226-230	Color 6
		231-235	Color 7
236-240	Color 8		
241-245	Color 9		
246-250	Color 10		
251-255	Color 11		

60	Foreground Dimmer	0-255	0-100%
61	Background	0-10	No Function
		11-255	Background Color
62	Background Dimmer	0-255	0-100%
63	Show	0-10	No Function
		11-24	Show1
		25-38	Show2
		39-52	Show3
		53-66	Show4
		67-80	Show5
		81-94	Show6
		95-108	Show7
		109-122	Show8
		123-136	Show9
		137-150	Show10
		151-164	Show11
		165-178	Show12
		179-192	Show13
		193-206	Show14
		207-220	Show15
		221-234	Show16
		235-248	Show17
249-255	Show18		
64	Show Speed	0-255	Show Speed Slow to Fast

14颗洗墙灯菜单(RGB)

版本号: V1.00

日期: 2018-12-21

d001(地址)	d(001-512)	
AUTO(自走)	Au.01(自走1)	S (01-16)自走速度
	Au.02(自走2)	
	...	
	Au.06(自走6)	
	Au.07(自走7)	
Soud(声控)	Sod1(声控1)	SC-(1-9)声控灵敏度
	Sod2(声控2)	
CH(模式)	CH03(3通道模式)	
	CH04(4通道模式)	
	CH06(6通道模式)	
	CH56(56通道模式)	
	CH58(58通道模式)	
	CH12(12通道模式)	
	CH64(64通道模式)	
TEST(测试)	LED(灯珠测试)	
Ver	V001	

